



Notes

1. PLC's are normally shipped with all outputs commons tied together. Separate COM2 from the others.

2. Wire collet P/S so contact closes when collet is closed. Set parameter #0 to 0 on bar feeder.

3. Connect these wires to interlock terminals (remove existing jumper)

4. Break spindle OFF/AUTO wire and splice these in